

## Function description for Pneumatic UL Genesis Blower model GB50-1AHT and GB50-1ANT

Before connecting the blower to mains, please select the wanted function. The PCB in the blower is preset from the factory with jumpers in positions 1 & 2. Position 3 is without jumper. The available functions are reached by removing the necessary numbers of jumpers, according to below mentioned instruction. Please remember to place the gasket and screw on the lid after function setting.

### **Jumpers in position 1 & 2 (Do not remove any of the jumpers):**

1. Press the pneumatic button: High Speed.
2. Press the pneumatic button: Medium Speed.
3. Press the pneumatic button: Low Speed.
4. Press the pneumatic button: Massage Mode.
5. Press the pneumatic button: OFF.

#### **Auto switch off:**

30 min. after the user operates the pneumatic button the last time, the blower will switch OFF automatically.

#### **Drying cycle:**

30 min. after manual or auto switch OFF, the blower starts up at High Speed for 2 sec. Then it drops to Low Speed and increases gradually to High Speed within half a minute. Then it continues running 4.5 min. at High Speed.

### **Jumper only in position 1 (Remove the jumper from position 2):**

1. Press the pneumatic button: High Speed.
2. Press the pneumatic button: Medium Speed.
3. Press the pneumatic button: Low Speed.
4. Press the pneumatic button: Massage Mode
5. Press the pneumatic button: OFF

#### **Auto switch off:**

30 min. after the user operates the pneumatic button the last time, the blower will switch OFF automatically.

#### **Drying cycle:**

30 min. after manual or auto switch OFF, the blower starts up at High Speed and runs at High Speed for 30 sec.

### **Jumper only in position 2: (Remove the jumper from position 1):**

1. Press the pneumatic button: The blower starts at High Speed for 2 sec. and then drops down to Increased Low Speed.
2. Press the pneumatic button: Medium Speed.
3. Press the pneumatic button: OFF

#### **Auto switch off:**

30 min. after the user operates the air switch the last time, the blower will switch OFF automatically.

#### **Remark:**

No High Speed except from the 2 sec. of start-up.

#### **Drying cycle:**

None.

### **No jumpers (Remove jumpers from position 1 & 2):**

1. Press the pneumatic button: The blower starts at High Speed for 2 sec. and then drops down to Low Speed.
2. Press the pneumatic button: Medium Speed.
3. Press the pneumatic button: OFF

#### **Auto switch off:**

30 min. after the user operates the pneumatic button the last time, the blower will switch OFF automatically.

#### **Remark:**

No High Speed except from the 2 sec. of start-up.

#### **Drying cycle:**

None.